

ELEVATOR

ROUTINE

PREVENTATIVE

MAINTENANCE

INSIDE THE CAR & OUTSIDE HOISTWAY

■ INSIDE THE CAR

- CAR INTERIOR**
- CAR CONTROLS & PANEL**
- LEVELING, STOPPING, ACCELERATION & DECELERATION**
- DOOR OPERATION**
- RIDE TERMINAL TO TERMINAL**
- CAR LIGHTS & VENTILATION**
- RESTRICTED OPENING DEVICE MECHANISM**

■ OUTSIDE HOISTWAY

- HALL CALL STATION & LANTERNS**
- HOISTWAY DOORS**
- HOISTWAY DOOR UNLOCKING DEVICE ACCESS**
- FIREFIGHTERS SERVICES TEST**

TOP OF CAR & PIT AREA

❖ TOP OF CAR

- ❖ STOP SWITCH
- ❖ TOP-OF-CAR OPERATING DEVICE & LIGHT
- ❖ CLEANLINESS
- ❖ TOP CAR GUIDE
- ❖ GUIDE RAILS
- ❖ SELECTOR TAPE
- ❖ TRAVELING CABLES
- ❖ DOOR OPERATOR
- ❖ DOOR HANGERS
- ❖ CAR FAN
- ❖ HOISTWAY CLEANING
- ❖ OTHER
- ❖ LEAVING CAR TOP

❖ PIT AREA

- ❖ GENERAL & SAFETY
- ❖ STOP SWITCH & LIGHT
- ❖ CLEANING
- ❖ OIL CONTAINER
- ❖ PLUNGER & CYLINDER
- ❖ BUFFERS
- ❖ BOTTOM CAR GUIDES
- ❖ TRAVELING CABLES
- ❖ SELECTOR TAPE TENSION SPRINGS
- ❖ SUMP PUMP
- ❖ LEAVING THE PIT

MACHINE ROOM

■ TRACTION


- HOUSEKEEPING
- TRASH & USED PARTS & OIL
- CONTROLLER & MOTOR STARTER
- MOTOR GENERATOR SET
- GOVERNOR
- TRACTION & GEARLESS DRIVE SHEAVE
- DEFECTOR SHEAVES
- BRAKE & BRAKE DRUM
- DRIVE MOTOR

■ HYDRAULIC

- HOUSEKEEPING
- TRASH & USED PARTS & OIL
- PUMPING UNIT INCLUDING MOTOR
- CONTROL VALVE TANK
- PIPING, MUFFLER & MANUAL VALVE
- CONTROLLER & MOTOR STARTER

PUBLIC RELATIONS

- **GENERAL**
- **DRESS**
- **APPEARANCE**
- **CONTACT WITH OTHERS**
- **FACILITY OPERATING PROCEDURES**
- **CHECK IN & CHECK OUT**
- **PAPERWORK**



LIFT TECHNOLOGIES, LLC

BE SAFE

&

WORK SAFE